

MaxxFlow HTC


Measurement of high mass flow rates for bulk solids



CONTENTS	Page
1. System Overview	3
2. Functionality	3
3. Safety	4
3.1 Normal Use	4
3.2 Identification of Hazards	4
3.3 Operational Safety	4
3.4 Technical Statement	4
4. Mounting and Installation	5
4.1 Supplied Equipment	5
4.2 Required Tools	5
4.3 Mounting of the Sensor	5
4.4 Overview of Connections between Sensor and Transmitter	7
4.5 Use in Ex Hazardous Areas	8
5. Electrical Connection	9
5.1 Version Field Housing	9
5.2 Version 19" Rack Mounted Transmitter	10
5.3 Version DIN Rail Transmitter	11
6. Commissioning	12
7. Standard Indication of MaxxFlow HTC	14
7.1 Transmitter with Display	14
7.2 PC-Software	15
8. Structure Main Menu MaxxFlow HTC	16
9. Using the PC-Software	18
10. System Adjustments in Detail	20
11. Connection Examples	29
12. Maintenance	30
13. Warranty	30
14. Trouble Shooting	30
15. Technical Data	31

1. System Overview

A MaxxFlo^w HTC measuring system consists of:



2. Functionality

- MaxxFlo^w HTC is a measuring system especially developed for the measurement of high mass flow rates in free fall applications.
- MaxxFlo^w HTC works with the latest microprocessor technology. By special capacitive coupling of an electromagnetic wave, a homogeneous measuring field is created inside the sensor.
- The electromagnetic wave inside the sensor interacts with the solid particles. The signals are evaluated regarding frequency and amplitude.
- The speed measurement is implemented by correlation. Two sensors are capturing the correlation signals.
- The measuring unit consists of the sensor (measuring pipe) and the transmitter.




Fig. 2: Coupling of the electromagnetic waves

3. Safety

The MaxxFlo HTC was designed, built and tested for safety and is shipped in this condition. Components within the supplied system could be hazardous if not unpacked, installed, connected and commissioned by authorised and qualified persons. All operating instructions must be read and understood before handling the system. Failure to do so will cause the warranty to be revoked.

3.1 Normal Use

- The measuring system must be installed for measuring mass flow rate only. Other usage or modifications of the measuring system are not permitted.
- Only original spare parts and accessories of SWR engineering must be used.

3.2 Identification of Hazards

- Possible hazards when using the measuring system are marked by the following symbols:



Warning!

- This symbolises a situation where personal safety is at risk if used in an improper manner.



Attention!

- This symbolises the possible damage to the system, if used in an improper manner.

3.3 Operational Safety

- The measuring system must be installed by trained and authorised personnel only.
- In case of maintenance-work on the pipe or on components of the MaxxFlo HTC, make sure that the piping is in unpressurized condition.
- Switch off the supply voltage for all maintenance, cleaning or inspection works on the sensor or on components within the MaxxFlo HTC. Follow the notes of the chapter maintenance.
- The components and electrical connections must be checked for damages regularly. If a damage is found it is to be repaired before further operation of the instruments.

3.4 Technical Statement

- The manufacturer reserves the right to change any technical data without prior notice. If any queries arise SWR engineering will be happy to inform customers of any possible changes made.

4. Mounting and Installation

4.1 Supplied Equipment

- Transmitter in field mounted enclosure, 19" rack version or DIN rail enclosure
- Sensor
- Operating Instructions

4.2 Required Tools

- Appropriately sized spanner or ring spanner
- Tools for electrical connections

4.3 Mounting of the Sensor

The sensor has to be mounted as follows:

- Select a location on the pipe, vertical or inclined locations. Ensure that the connection box cable glands are pointing downwards.
- Ensure that the correct distance is selected from control devices, e. g. rotary valves, etc. As this will determine velocity criteria, (see fig. 3).




Fig. 3: Minimal distances of the sensor to control devices

Installations in angular pipes are as well possible. If you are unsure contact SWR staff.



Attention!

- Before installation check that flange alignment is correct and there is no residual debris within the sensor.



Fig. 4: Mounting of the measuring tube

- Depending on cable on size, the maximum distance between sensor and transmitter is 300 m.

It is recommended to install the transmitter in any switching room, control room or any other shielded area to protect from dust, humidity, temperature, vibration or any other influences.



or



or



Fig. 5: Transmitter

4.4 Overview of Connections between Sensor and Transmitter





Fig. 6: Wiring of the sensor pipe and transmitter

Depending on cable cross sectional area, the maximum distance between sensor and transmitter is 300 m. A four (4) core shielded cable should be used.

4.5 Use in Ex Hazardous Areas

Marking DustEx:



II 3D Ex tD A21
Zone 22: $0\text{ °C} \leq T_{\text{prozess}} \leq 80\text{ °C}$

- Equipment group: 2
- Equipment category: 3
- For combustible mixtures of air and dust
- IP 65
- Maximum surface temperature 84 °C with $T_a = 60\text{ °C}$

Marking GasEx:


II 3G Ex e IIC T4

- Equipment group: 2
- Equipment category: 3
- Zone 2
- For combustible mixtures of air and gas
- Allowable process temperature 0 to 80 °C
- Temperature class, T4
- Maximum surface temperature 84 °C with $T_a = 60\text{ °C}$



5. Electrical Connection

5.1 Version Field Housing




Fig. 8: Electrical Connection

Transmitter			
Terminal No.	Connection		
Connection of the power supply			
L / +24 V	Input power supply 230 V/50 Hz, 110 V/60 Hz (optional 24 V DC)		
N / 0 V	Input power supply 230 V/50 Hz, 110 V/60 Hz (optional 24 V DC)		
PE	Protective Earth		
Connections			
I-in 1	Na	not available	
	Na	not available	
I-out 1	+	Current Output 4 ... 20 mA +	Flow
	-	Current Output 4 ... 20 mA - (GND)	
I-out 2	+	Current Output 4 ... 20 mA +	Density
	-	Current Output 4 ... 20 mA - (GND)	
I-out 3	+	Current Output 4 ... 20 mA +	Velocity
	-	Current Output 4 ... 20 mA - (GND)	
Alarm Relay	NO	Isolated Relay Contact NO (make contact)	
	C	Isolated Relay Contact COM (common contact)	
	NC	Isolated Relay Contact NC (break contact)	
D-out	+	Digital Output (+)	
	-	Digital Output (-)	
RS 485	A	RS 485 Interface Data A (+)	
	B	RS 485 Interface Data B (-)	
	GND	RS 485 Interface Ground	
D-in 1	+	Digital Interface 1 (+)	
	-	Digital Interface 1 (-)	
D-in 2	+	Digital Interface 2 (+)	
	-	Digital Interface 2 (-)	
Sensor	+	Power supply 24 V (+)	Cable No. 1
	-	Power supply GND	Cable No. 2
	A	RS 485 Data A	Cable No. 3
	B	RS 485 Data B	Cable No. 4
	Shield	Shield	Shield

5.2 Version 19" Rack Mounted Transmitter





Fig. 9: Electrical Connection

Transmitter		
Terminal		Function
Connection of Power Supply		
+ 24 V DC	2 a/c + 4 a/c	Input Power Supply + 24 V DC
0 V GND	6 a/c + 8 a/c	Input Power Supply GND
PE	30 a/c	Protective Earth
Terminals		
RS 485 System / PC	10 a	RS 485 Interface Data A (+)
	12 a	RS 485 Interface Data B (-)
Relay NO	14 a	Relay Contact 1
	14 c	Relay Contact 2
Current Output 1 Flow Rate	16 a	4 ... 20 mA I-out 1 (-)
	16 c	4 ... 20 mA I-out 1 (+)
Current Output 2 Density	18 a	4 ... 20 mA I-out 2 (-)
	18 c	4 ... 20 mA I-out 2 (+)
Current Output 3 Velocity	20 a	4 ... 20 mA I-out 3 (-)
	20 c	4 ... 20 mA I-out 3 (+)
Digital Input 1	22 a	Dig. In 1 (-)
	22 c	Dig. In 1 (+)
Digital Input 2	24 a	Dig. In 2 (-)
	24 c	Dig. In 2 (+)
Impulse Output	26 a	Dig. Out (-)
	26 c	Dig. Out (+)
Sensor Connections	28 a/c	Output Power Supply 24 V DC
	32 a/c	Output Power Supply 0 V GND
	10 c	Output RS 485 Interface Data A (+)
	12 c	Output RS 485 Interface Data B (-)

5.3 Version DIN Rail Transmitter

1 Current output - 4 ... 20 mA	2 Current output + 4 ... 20 mA	3 Input power supply 0 V DC	4 Input power supply + 24 V DC
5 not available	6 Alarm relay NC	7 Alarm relay C	8 Alarm relay NO



9 not available	10 not available	11 RS 485- Interface data B	12 RS 485- Interface data A
13 Sensor connection cable 4 RS 485 data B	14 Sensor connection cable 3 RS 485 data A	15 Sensor connection cable 2 Power supply 0 V	16 Sensor connection cable 1 Power supply + 24 V

6. Commissioning

Please check again:

- That all connections between the sensor and transmitter are correct.
- That the sensor is correctly installed.
- If there are problems at this stage, please contact your local distributor or SWR directly.
- Apply power to the system. Wait for a warm up period of fifteen (15) minutes before starting any adjustments.

There are different possibilities to commission MaxxFlow HTC:

Nearly every MaxxFlow application is based on free falling or sliding material, so the velocity could be assumed as a constant. Therefore it is recommended to use the fixed velocity option because this will be the most reliable operation mode.

a. calibration via full-adjusting

Switch on fixed velocity option and ensure that RMS-A (root mean square of velocity signal A) is higher than NST (no signal threshold) during flow condition.

If necessary proceed a zero calibration, than fill up the sensor with material and proceed a full calibration (Menu 2.1.3). Assumed the falling height has been set correctly (Menu 1.7), this should result in a real flow indication now. If there is still some deviation adjust the flow value from now on with the calibration factor.

Zero calibration: Start zero-point calibration (Menu 2.1.1) in no-flow condition with empty pipe. Insure that the pipe is really empty.

b. Calibration via calibration factor and reference

Switch on fixed velocity option and ensure that RMS-A is higher than NST during flow condition. If necessary proceed a zero calibration.

It is not necessary to proceed any full calibration or flow calibration, you are able to work with the factory setting. For calibration you only have to adjust the calibration factor (Menu 2.2) according to a comparison of a reference value with the flow indication. The calibration factor could be calculated using this formula:

$$\frac{\text{Reference value}}{\text{MaxxFlow HTC indication}} \times \text{actual calibration factor} = \text{new calibration factor}$$

c. Calibration via working point

Switch on fixed velocity option and ensure that RMS-A is higher than NST during flow condition. If necessary proceed a zero calibration.


For this kind of calibration you need 2 measuring points. Measuring point 1 must be the zero point, Measuring point 2 would be the working point (Menu 2.1.2).

The working point should be set while a stable operating flow is given and the flow value is known. After later weighing this value can be adjust via the corrector factor.

Basic function	At least a two-point-calibration (normally zero and max) is sufficient for the density measurement. The velocity measurement, if used in fact, is firmly defined as an absolute measurement by the distance of the sensor plates and does not have to be calibrated.
Zero-point	Start zero-point calibration in no-flow condition with empty pipe. Insure that the pipe is really empty.
Operating-point	Start operating-point calibration during flow condition with known flow value. It is possible to edit this value at a later time.
Analog output 1	Current output flow rate. The measuring range is adjusted in menu point 3.1.1. 0 = 4 mA Max = 20 mA
Analog output 2	Current output density. The measuring range is adjusted in menu point 3.2.1. 0 = 4 mA Max = 20 mA
Analog output 3	Current output speed. The measuring range is adjusted in menu point 3.3.1. 0 = 4 mA Max = 20 mA
Filter	The filter values visible in the analog output configuration are used to smooth the continuous analogue output trend.

7. Standard Indication of MaxxFlo HTC

7.1 Transmitter with Display



The standard display shows the actual flow rate as well as measuring values of density, velocity and the totaliser value.

With four touch screen buttons, further indication and configuration information is available:

- R** Reset totaliser, choose OK or NO
- D** Density, further informations about density measurement, back with **M** (mass flow)
- V** Velocity, further information about speed measurement, back with **M** or press **S** (speed) for velocity configuration.
- S** V-Adjustment, various settings for speed measurement.

1. Threshold

It defines the noise level of the RMS values (root mean square values) of the velocity signals. All values below will be ignored for speed measurement resp. with activated fix-velocity the output will switch to 0 m/s.

Possible values 1 - 65535, cancel with **E** (ESC)

V-Adjustment Threshold 230 Eff-Value = 135	7	8	9
	4	5	6
	1	2	3
	E	0	←

2. Display of the actual RMS value of velocity signals

3. Fix-velocity

Setting of fix-velocity value, this will replace automatically the parameter falling height.

Possible values 1 - 99.99, cancel with **E** (ESC)

V-Adjustment Fix-Velocity 2.30 m/s	7	8	9
	4	5	6
	1	2	3
	E	0	←

4. Vfix


Fix-Velocity **On / Off**

T Displays the temperature of the sensor electronics.

7.2 PC-Software

For systems without display a PC-Software is available.


The default display showing is represented here by the online representation.



The basic settings for using the software are described in a later chapter.

In the following the menu navigation via display will be describe. These menu points are the same like in the PC-Software, so the using is derives therefrom.

8. Structure Main Menu MaxxFlo HTc



Switch to main menu: Press any pad of the touchscreen for about a few seconds until the menu appears.

1. Measurement

- | | |
|------------------------|------------------------|
| 1.1 Tag | Name (10 characters) |
| 1.2 Unit | Select: g / kg / t |
| 1.3 Time Unit | Select: h / min / s |
| 1.4 Dec. Point | Position of dec. point |
| 1.5 Density | Range 1 --- 3000 g/l |
| 1.6 Aperture | Range 10 --- 300 mm |
| 1.7 Drop Height | Range 10 --- 9999 mm |

2. Calibration

- | | |
|----------------------------------|--|
| 2.1 Sensor Calibration | Adjusting the measured value to material and mounting situation. |
| 2.1.1 Zero Point | ... for the empty sensor |
| 2.1.2 Operating Point | ... with material flowing |
| 2.1.3 Full Calibration | ... with filled sensor |
| 2.2 Current Input | Adjustment of current input for external correction |
| 2.2.1 Calibration 4 mA | Factory setting, no adjustment required |
| 2.2.2 Calibration 20 mA | Factory setting, no adjustment required |
| 2.3 Factor | Correction factor density, Range 0.01 --- 9.99 |
| 2.4 Interpolation Points | Amount of interpolation points for linearization (max. 3) |
| 2.5 Interpolation Table | Linearization characteristic |
| 2.6 Min. Load | Suppression of conveying dropouts during auto acquisition |
| 2.7 Interpolation Point 1 | |
| 2.7.1 Raw Value | Non-linearized flow rate |
| 2.7.2 Calibrated Value | Linearized flow rate |
| 2.7.3 Auto Acquisition | Automatic calibration with a weighed mass |
| 2.8 Interpolation Point 2 | Same as interpolation point 1 |

3. Outputs

3.1 Flow Rate

3.1.1 at 20 mA

End of measuring range

3.1.2 Filter

Range: 0.1 --- 99.9 s (Standard: 1 s)

3.1.3 Calibration 4 mA output

Factory setting, no adjustment required

3.1.4 Calibration 20 mA output

Factory setting, no adjustment required

3.2 Density

3.2.1 at 20 mA

End of measuring range

3.2.2 Filter

Range: 0.1 --- 99.9 s (Standard: 1 s)

3.2.3 Calibration 4 mA output

Factory setting, no adjustment required

3.2.4 Calibration 20 mA output

Factory setting, no adjustment required

3.3 Velocity

3.3.1 at 20 mA

End of measuring range

3.3.2 Filter

Range: 0.1 --- 99.9 s (Standard: 1 s)

3.3.3 Calibration 4 mA output

Factory setting, no adjustment required

3.3.4 Calibration 20 mA output

Factory setting, no adjustment required

3.4 Alarm

3.4.1 Type

Select: Minimum or maximum alarm

3.4.2 Value

Flow value triggering an alarm

3.4.3 Delay

Range: 0.1 --- 99.9 s

3.4.4 Hysteresis

Threshold for resetting the alarm

3.4.5 Output

Select alarm: Alarm or sensor busy

3.4.6 Mode

Select relais mode: NO / NC

3.4.7 Sensor alarm

Select: ON / OFF

3.5 Impuls Output

3.5.1 Pulse / Mass

Desired number of pulses per mass unit counted by the totalizer

4. Digitale Inputs

4.1 Digital Input 1

4.1.1 Function

Selection of function
none / zero adjustment / full adjustment

4.1.2 Direction

Select: direct / inverted

4.1.3 Filter

Range: 0.1 --- 99.9 s

4.2 Digital Input 2

4.2.1 Function

Selection of function
none / zero adjustment / full adjustment

4.2.2 Direction

Select: direct / inverted

4.2.3 Filter

Range: 0.1 --- 99.9 s

5. System

5.1 Baud Rate

Select: 4800 / 9600 / 19200 / 38400

5.2 Address

Range: 1 --- 250


5.3 Contrast

Contrast adjustment

5.4 Language


Select: D / F / E

9. Using the PC-Software



Interface	Choice of the serial interface in the PC (COM 1 ... COM 12)
ModBus address	Address of the appealed transmitter in the ModBus (1 ... 255)
Baud rate	Information of the Baud rate for serial communication (4800 / 9600 / 19200 / 38400 Bd - Standard 9600 Bd)
Device read	All parameters are read from the transmitter linked with the PC and are shown.
Device program	The changed parameters are written in the transmitter and are stored there. Without putting of the brand calibration headline, if all changes are taken over without calibrating data in menu point 4. With putting of the brand calibration headline, if the changes of the calibrating data from menu 4 are also sent to the transmitter.

- Online-representation** Online-representation of the measuring values on the PC:
- Mass Flow:** Announcement of the measuring value in phys. units.
 - Speed:** Notification of the fix- or the real-speed.
 - Density:** Announcement of the measuring density in phys. units.
 - Totalizator:** Throughput counter as a calibrating aid.
 - Reset:** Put back of the totalizer on 0.
 - Data-logger on:** After the input of a file name and the choice of the memory rate, the data are stored in the CSV format. Afterwards these data can be worked on with Excel or a similar program and be analyzed.



- Data-logger setting** Information of the memory rate 1/s, 20/s, 10/min . . . for saving data.
For using data-logger it is necessary to set a file name before.
- File name** Set file path and name for saving the CSV data.
- Save configuration** Save hole configuration of the transmitter on the PC.
- Load configuration** Load configuration for transmitter which is stored on PC.
- Print configuration** Print the actual configuration of the transmitter in table format.
- Language** With pressure the right mouse key on Language in the lowest task strip, appears the linguistic choice: D / F / E .

10. System Adjustments in Detail

1. MEASUREMENT

1.1 Tag

Freely selectable notation, max. 10 characters.

With and select characters, with and select place of the character (1...10); with delete the respective character, with leave without changes, and with confirm and leave the menu level.

Measurement Tag		
MaxxFlow		

1.2 Unit

Selection of the mass unit: g / kg / t

With and select according to the display, with leave the menu without any change, with confirm and leave the menu level.

Measurement Unit	
t	

1.3 Time Unit

Select of the time unit - Choose: h / min / s
 / s per second
 / min per minute
 / h per hour

With and select the time unit with leave the menu without any change, with confirm and leave the menu level.

Measurement Time Scale	
h	

1.4 Decimal Point

Adjust the decimal place in the display.

With and select according to the display, with leave the menu without any change, with confirm and leave the menu level.

Measurement Range Decimal Point	
000.0	

1.5 Density

Set bulk density in g/l (= kg/m³), possible range 1 to 3000 g/l.

Enter the value, with leave without changes, with confirm and leave the menu level.

Measurement Bulk Density	7	8	9
1250 g/l	4	5	6
	1	2	3
	E	0	

1.6 Aperture

Set value of inner pipe diameter.

Enter the value, with **[E]** leave without changes, with **[↵]** confirm and leave the menu level.

Measurement Aperture 150 mm	7	8	9
	4	5	6
	1	2	3
	E	0	↵

1.7 Drop Height

Enter drop height, this will calculate fixed-velocity value automatically.

Enter the value, with **[E]** leave without changes, with **[↵]** confirm and leave the menu level.

Measurement Drop Height 265 mm	7	8	9
	4	5	6
	1	2	3
	E	0	↵

2. CALIBRATION

2.1 Sensor Calibration

2.1.1 Zero Point

Insure that the pipe is empty.
Start zero adjustment with **[OK]**.
Cancel with **[NO]**.

Zero Point Calibration in Progress . . .	
Range	7
Offset	378
Density	22

2.1.2 Operating Point

Enter known flow rate.

Enter the value, with **[E]** leave without changes, with **[↵]** confirm and go to the next window.

Change filter value with **[Z]**, confirm adjustment values with **[↵]**.

Sensor Calibration Operating Point 57 t/h Qmax = 127 @ 1.8 m/s	7	8	9
	4	5	6
	1	2	3
	E	0	↵

Operating Point Adjustment at	C
57 t/h	↵
Raw Value = 101	
Filter = 10 s	Z

Display during calibration procedure.

Operating Point Calibration in Progress . . .	
Density	782

2.1.3 Full Calibration

Calibration with 100 % filled pipe in no-flow condition.

Set full calibration with **[OK]**.
Cancel with **[NO]**.

Full Point Calibration in Progress . . .
Density 782

2.2 Stromeingang

2.2.1 Kalibrierung 4 mA

Stromeingang Kalibrierung 4 mA	
511	[C]
Akt.: 0	[←]

2.2.2 Kalibrierung 20 mA

Stromeingang Kalibrierung 20 mA	
511	[C]
Akt.: 0	[←]

2.3 Factor

Correction factor affects directly the density measurement.

0.01 to 9.99

Default 1.0

Enter the value, with **[E]** leave without changes, with **[←]** confirm and leave the menu level.

Calibration Factor	7	8	9
1.0	4	5	6
	1	2	3
	E	0	[←]

2.4 Interpolation Points

Set amount of required interpolation points; maximum 3 points are possible.

Enter the value, with **[E]** leave without changes, with **[←]** confirm and leave the menu level.

Interpolation Points	7	8	9
2	4	5	6
	1	2	3
	E	0	[←]

2.5 Interpolation Table

Display of the calibrated points.

Back with **[E]**.

Interpolation Table		
	raw	calibrated
1.	57	57 t/h
2.	84	84 t/h
[E]		

2.6 Min. Load

Suppresses conveying breaks during Auto Acquisition.

Enter the value, with **[E]** leave without changes, with **[←]** confirm and leave the menu level.

Calibration Min. Load	7	8	9
10 %	4	5	6
	1	2	3
	E	0	[←]

2.7 Interpolation Point 1

2.7.1 Raw Value

Manual interpolation.
This is the non-linearized flow value.

Enter the value, with **[E]** leave without changes, with **[↵]** confirm and leave the menu level.

Interpolation Point 1 Raw Value	7	8	9
57 t/h	4	5	6
	1	2	3
	E	0	↵

2.7.2 Calibrated

Manual interpolation.
Linearized flow value.

Enter the value, with **[E]** leave without changes, with **[↵]** confirm and leave the menu level.

Interpolation Point 1 Calibrated	7	8	9
57 t/h	4	5	6
	1	2	3
	E	0	↵

2.7.3 Auto Acquisition

Enables a calibration by means of a weighed mass. The collection of data starts with entering this menu point, but only flow rates above the min. load value will be counted.

Finish with **[↵]**, enter the conveyed mass and confirm with **[↵]**. Press **[E]** to leave menu point without any changes.

Auto Acquisition Button [C] break Button [ENTER] finish Collected Data: 276 probes	C	↵
---	---	---

Charged Amount	7	8	9
57 t	4	5	6
	1	2	3
	E	0	↵

2.8. / 2.9 Interpolation point 2 / 3 same as point 1

3. OUTPUTS

3.1 Output 1 Flow Rate

3.1.1 at 20 mA

Enter end of measuring range, this will comply to 20 mA.

Enter the value, with **[E]** leave without changes, with **[↵]** confirm and leave the menu level.

Flow Rate Value at 20 mA	7	8	9
100 t/h	4	5	6
	1	2	3
	E	0	↵

3.1.2 Filter


Adjustable damping for the flow rate.
Range: 0.1 . . . 99.9 s (Standard 1 s)

Enter the value, with **[E]** leave without changes, with **[↵]** confirm and leave the menu level.

Flow Rate Filter	7	8	9
1.0 s	4	5	6
	1	2	3
	E	0	↵

3.1.3 Calibration 4 mA


All current outputs were calibrated at the factory.
If necessary recalibration with multimeter is possible.



With << and >> adjust fast, with < and > adjust slowly the current to 4 mA. With confirm and leave the menu level, with C leave the menu without any change.

3.1.4 Calibration 20 mA

All current outputs were calibrated at the factory.
If necessary recalibration with multimeter is possible.




With << and >> adjust fast, with < and > adjust slowly the current to 4 mA. With confirm and leave the menu level, with C leave the menu without any change.

3.2. Output 2 Density

3.2.1 at 20 mA


Enter end of measuring range, this will comply to 20 mA.



Enter the value, with E leave without changes, with confirm and leave the menu level.

3.2.2 Filter


Adjustable damping for the density.
Range: 0.1 ... 99.9 s (Standard 1 s)



Enter the value, with E leave without changes, with confirm and leave the menu level.

3.2.3 Calibration 4 mA


All current outputs were calibrated at the factory.
If necessary recalibration with multimeter is possible.



With << and >> adjust fast, with < and > adjust slowly the current to 4 mA. With confirm and leave the menu level, with C leave the menu without any change.

3.2.4 Calibration 20 mA

All current outputs were calibrated at the factory.
If necessary recalibration with multimeter is possible.




With <<< and >>> adjust fast, with < and > adjust slowly the current to 4 mA. With ↵ confirm and leave the menu level, with C leave the menu without any change.

3.3 Output 3 Speed

3.3.1 at 20 mA


Enter end of measuring range, this will comply to 20 mA.



Enter the value, with E leave without changes, with ↵ confirm and leave the menu level.

3.3.2 Filter


Adjustable damping for the velocity.
Range: 0.1 . . . 99.9 s (Standard 1 s)



Enter the value, with E leave without changes, with ↵ confirm and leave the menu level.

3.3.3 Calibration 4 mA


All current outputs were calibrated at the factory.
If necessary recalibration with multimeter is possible.



With <<< and >>> adjust fast, with < and > adjust slowly the current to 4 mA. With ↵ confirm and leave the menu level, with C leave the menu without any change.

3.3.4 Calibration 20 mA

All current outputs were calibrated at the factory.
If necessary recalibration with multimeter is possible.



With <<< and >>> adjust fast, with < and > adjust slowly the current to 4 mA. With ↵ confirm and leave the menu level, with C leave the menu without any change.

3.4 ALARM

3.4.1 Type

Upper and lower limit value. Affects relays.

With and select according to your significance, with leave the menu without any change, with confirm and switch to a deeper menu level.

Alarm				
Alarm type				
Maximum				

3.4.2 Value of Alarm

Flow value for the alarm.

With leave the menu without any change, with confirm and leave the menu level.

Alarm				7	8	9
Value of Alarm				4	5	6
90 t/h				1	2	3
				E	0	

3.4.3 Delay

Threshold value how long the value must be over or under the limit until the alarm relay reacts.

Range: 0.1 ... 99.9 s

With leave the menu without any change, with confirm and leave the menu level.

Alarm				7	8	9
Delay				4	5	6
1.0 s				1	2	3
				E	0	

3.4.4 Hysteresis

Threshold for resetting the alarm.

Range: 0 ... 500 t/h

With leave the menu without any change, with confirm and leave the menu level.

Alarm				7	8	9
Hysteresis				4	5	6
85 t/h				1	2	3
				E	0	

3.4.5 Output

Alarm / calibration active

Selection of signalisation mode using the relay either as "Alarm" or "Sensor busy" for auto calibration unit.

With and select according to the display, with leave the menu without any change, with confirm and leave the menu level.

Alarm				
Output				
Alarm				

3.4.6 Mode

Choice of the contact work or interruption.

NO - Working current





NC - Static current





With and select according to the display, with leave the menu without any change, with confirm and leave the menu level.

Alarm				
Operation Mode				
NO				

3.4.7 Sensor Fault

On / Off
Affects to alarm relay.

With  and  select according to the display, with  leave the menu without any change, with  confirm and leave the menu level.


Alarm Sensor Fault	
on	
	
	



3.5 Pulse Output

The pulse output is potential free (optocoupler), wiring see page 29.

3.5.1 Amount of Pulses / Mass Unit

Type desired number of pulses per mass unit. This should not exceed 50 Hz.

Pulse Output Mass / Pulse	7	8	9
10.00	4	5	6
	1	2	3
	E	0	

Input with the count keyboard. With  leave the menu without any change, with  confirm and leave the menu level.





4. DIGITAL INPUTS





The digital inputs are potential free (optocoupler), wiring see page 29.

4.1 Digital Input 1

4.1.1 Function





Digital input for a trigger signal to start zero or full calibration.
Select input function.
None / S-Zero / S-Full





Digital Input 1 Function	
S-Full	
	
	

Possibility to start calibration with an external signal. With  and  select according to the display, with  leave the menu without any change, with  confirm and leave the menu level.

4.1.2 Direction



Direct / Inverted


With  and  select according to the display, with  leave the menu without any change, with  confirm and leave the menu level.

Digital Input 1 Direction	
direct	
	
	

4.1.3 Filter

Idle time after activation.

With  leave the menu without any change, with  confirm and leave the menu level.

Digital Input 1 Filter	7	8	9
0.0 s	4	5	6
	1	2	3
	E	0	

4.2 Digital Input 2


Same as Digital Input 1

5. SYSTEM

5.1 Baud Rate

Baud Rate Setting
 Select: 4800 / 9600 / 19200 / 38400


With and select Baud Rate, with leave the menu without any change, with confirm and leave the menu level.



5.2 ModBus-Address

Set 1 . . . 250


With leave the menu without any change, with confirm and leave the menu level.



5.3 Contrast

Display contrast for a better legibility.


With and adjust fast, with and adjust slowly to the required contrast. With confirm and leave the menu level, with leave the menu without any change.



5.4 Language


Language selection.
 Choose: D / F / E

With and select language, with leave the menu without any change, with confirm and leave the menu level.




11. Connection Examples

11.1 Digital Input



11.2 Impulse Output



12. Maintenance



Warning!

- Beware of live terminals when opening enclosure.
- Ensure power is disconnected before undertaking any maintenance.
- Repairs and maintenance must only be carried out by trained authorised persons.

13. Warranty

Warranty is for one (1) year. It starts from the delivery date. The warranty is valid as long as the system has been installed and commissioned according to the Operating Instructions and there is no sign of any wear or mechanical damage.

In the case of defects during the warranty period, all defective components will be repaired / replaced. The parts that are replacing the defective parts, remain the property of SWR. If the customer requires the warranty work to be executed at their premises, then the customer will pay for costs of the SWR engineer to be on their site.

SWR is not responsible for any damage to the customer's process and is not responsible for any loss of profit due to that damage.

14. Trouble Shooting



Warning!

- The electrical installation must be carried out by qualified, authorised persons.

Problem	Cause	Solution
System does not operate.	No power.	Check power supply.
	Cable break.	Check for continuity.
	Defective device.	Replace fuses in enclosure.
Outputs are the wrong values.	Incorrect calibration.	Re calibrate the system.
Sensor error.	Sensor connections incorrect.	Check wiring connections.
	Sensor failure.	Replace sensor.
Do not open sensor electronics. To do so will make the warranty void.		

15. Technical Data

Sensor	
Housing	St52, powder coated (optional stainless steel 1.4571) NW 100 / 150 / 200, flange according EN 1092-1 / PN 10
Inner pipe	Ceramic (Al ₂ O ₃)
Protection category	IP 65, ATEX: Cat. 3D
Environment temperature	Sensor pipe: -20 ... + 120 °C Sensor electronic: 0 ... + 60 °C
Max. working pressure	1 bar (optional 10 bar)
Working frequency	88 kHz
Transmitting power	Max. 2 mW
Weight	Depending to model
Accuracy	+/- 3 % (based on end of measuring range)
Transmitter (version field housing)	
Power supply	110 / 240 V AC, 50 Hz, 24 V DC
Power consumption	20 W 24 VA
Protection category	IP 65 according EN 60 529/10.91
Dimensions	258 x 237 x 174 (W x H x D)
Weight	Approx. 2.5 kg
Terminal clamp wire size	0.2 - 2.5 mm ² [AWG 24-14]
Cable Glands	3 x M16 (4.5 - 10 mm Ø)
Alarm output Error output	Relay with toggle switch - max. 250 V AC, 1 A
Transmitter (version 19" rack system)	
Power supply	24 V DC
Power consumption	12.5 W
Protection category	IP 30 according EN 60 529/10.91
Dimensions	19" rack system, 3HE, 28TE, L = 227 mm
Weight	Approx. 1 kg
Connection	Connector (DIN 41612), Typ B, 32-pol., connector
Alarm output	Relay NC - max. 250 V AC, 1 A
Transmitter (version DIN rail)	
Power supply	24 V DC ± 10 %
Power consumption	20 W 24 VA
Protection category	IP 40 according EN 60 529
Operating temperature	-10 ... +45 °C
Dimensions	23 x 90 x 118 (W x H x D)
Weight	Approx. 172 g
DIN Rail mounting	DIN 60715 TH35
Terminal clamp wire size	0.2 - 2.5 mm ² [AWG 24-14]
Current output signal	4 ... 20 mA (0 ... 20 mA), load < 500 Ω
Alarm output	Relay with switching contact - Max. 250 V AC, 1 A
Data backup	Flash
Additional Data	
Operating temperature	-10 ... +45 °C
Current outputs	3 x 4 ... 20 mA (0 ... 20 mA), load < 500 Ω
Digital inputs	2 x Ri 2 kΩ, 5 - 50 mA
Data storage	Flash Memory
Impulse output	Open Collector - Max. 30 V, 20 mA
USB interface	2.0
RS 485 interface	ModBus-Protocol