



OPERATING INSTRUCTIONS

AirFlow P

VOLUME CURRENT MEASUREMENT



For the 1st use of the sensor, correct sensor type should be selected via the screen or the software. Software must be installed if needed.

1. SOFTWARE INSTALLATION


If you want to communicate with our sensor using our dedicated software, you need to download the latest version on our website and install it.

→ <https://www.envea.global/solutions/process-optimization/dahs-software/>

It might also be necessary to install drivers, also available on our website.


2. MSE 300-FH (WITH SCREEN)

The display is touch-sensitive. Available keys are displayed directly in context. When the measuring system is first started, a query is initiated to select the language and sensor.




Initialization screen when the Evaluation unit in the field housing started first time.

Selection of the menu language: Deutsch, English, Français.



If a language has been selected, the sensor to be used must be selected. To be available:

SolidFlow 2.0, Paddy, PicoFlow, MaxxFlow HTC, DensFlow, SpeedFlow 2.0, SlideControl 2.0, ProSens, M-Sens 2, M-Sens 3, M-Sens WR, M-Sens WR2.




If any data has been changed, the change will only be taken into account when you exit the complete menu structure and answer [Yes] when asked if you wish to save the changes. Afterwards the start page appears.

3. MSE 300-DR / -DR2 (NO SCREEN)


Our dedicated software must be used to connect to the sensor evaluation unit.

Select software language




Right click on „Sprache/Language/ Langue“ and select desired language.

Connect to sensor



Select the correct COM port and connect to the device using the „read device“ button.


Select correct sensor



In the menu „System“, under „Sensor“ (8.2.5 or 7.2.5), the correct sensor must be selected.

After selecting the sensor, check the box „Overwrite measurement calib.“ and confirm with the button „Device program“.

For more informations and details, please refer to the user manual of the sensor.



CONTENTS

Page

1. System overview	5
2. Function	7
3. Safety	8
3.1 Normal use	8
3.2 Identification of hazards	8
3.3 Operational safety	8
3.4 Technical statement	8
3.5 Reliability	8
4. Mounting and installation	9
4.1 Supplied equipment	9
4.2 Required tools	9
4.3 Determining the installation position	9
4.4 Installation in non-metallic lines	10
4.5 Installation of the sensor	11
4.6 Dimensions	12
5. Electrical connection	15
5.1 Terminal assignment MSE 300-DR	15
5.2 Terminal assignment MSE 300-FH	16
5.3 Terminal assignments C-Boxes	17
5.4 Terminal assignment sensor	18
6. Operator interface	19
6.1 Differences between the Evaluation units DIN rail or field housing	19
6.2 Display	20
6.3 PC interface	22
6.4 Menu structure	24
7. Start-up procedure	34
7.1 Basic start-up procedure	34
7.2 Datalogger function of the software	34
7.3 Adjusting the measurement values	35
8. Error signalling	36
9. Maintenance	37
10. Warranty	37
11. Troubleshooting	37
11.1 Error codes	38
12. Technical data	39

1. System overview

A measuring point consists of the components:

- Evaluation unit (MSE 300) in DIN rail housing (-DR) or field housing (-FH)
- Double weld-on socket for sensor mounting
- Sensor (consisting of 2 x antenna, 1 x electronic box)
- Assembly instructions
- Optional: C1 or C3 box




Fig. 1: Overview with C1-Box and MSE 300-FH





Fig. 2: Overview with C1-Box and MSE 300-DR



The system can be equipped with up to three sensors. Accordingly, different C-Boxes (C1, C3) are used.




Fig. 3: Overview with C3-Box and MSE 300-FH




Fig. 4: Overview with C3-Box and MSE 300-DR

2. Function

The AirFlow P is a volumetric flow meter specially designed for dusty applications.

The sensor technology is based on the electrodynamic measuring principle. Every particle that flies past the antenna within a radius of 300 mm generates an electrical signal. The signals from the two antennas are further processed in the sensor's electronics box. The electronics box of the sensor correlates the received signals of both antennas with each other and thus determines the velocity.

For an output of the volume flow, the area of the pipe to be monitored must be stored in the evaluation unit. The evaluation unit then calculates the measured velocity with the specified area ($A \times v = \text{m}^3/\text{time}$).

The AirFlow P can also be used for pure speed measurement.





Fig. 5: AirFlow P in a pipeline



3. Safety

The AirFlow P measuring system has been designed, built and tested in accordance with the latest state of the art and has left the factory in perfect condition. Nevertheless, system components can pose hazards to persons and property if they are operated improperly.

The operating instructions must therefore be read in full and the safety instructions observed. In case of improper and intended use, any liability and warranty by the manufacturer is rejected.

3.1 Normal use

- The measuring system must be installed for measuring mass flow rate only. Other usage or modifications of the measuring system are not permitted.
- Only original spare parts and accessories of ENVEA Process must be used.

3.2 Identification of hazards

- The following symbols are used in the operating instructions to indicate possible dangers when using the measuring system:



Warning!

- This symbol indicates actions in the operating instructions which, if not carried out correctly, could endanger the life and limb of persons..



Attention!

- This symbol is used in the operating instructions to indicate all actions that may cause possible danger to property.

3.3 Operational safety

- The measuring system may only be fitted and installed by trained and authorized personnel.
- Make sure that the system is in a depressurized state during all maintenance, cleaning and inspection work on the pipelines or on the components of the AirFlow P.
- Switch off the supply voltage for all maintenance work, cleaning work and inspections on the pipelines or on the components of the AirFlow P. Observe the instructions in the chapter Maintenance and Care.
- Before welding work, the sensor must be removed from the pipeline.
- The components and electrical connections must be checked for damage at regular intervals. If there is any damage, it must be repaired before further operation of the devices.

3.4 Technical statement

- The manufacturer reserves the right to adapt technical data to technical development progress without special notice. ENVEA Process will be pleased to provide information about the up-to-dateness and possible changes and extensions of the operating instructions.

3.5 Reliability

For more information on the reliability of the product, contact ENVEA Process.

4. Mounting and installation

4.1 Supplied equipment

- Evaluation unit (MSE 300) in DIN rail housing (-DR) or field housing (-FH)
- Double weld-on socket for sensor mounting
- Sensor (consisting of 2 x antenna, 1 x electronic box)
- Assembly instructions
- Optional: C1 or C3 box

4.2 Required tools

- Open-end wrench (36 mm)
- PZ 2 cross-recess screwdriver
- Suitable tools for the electrical connection

4.3 Determining the installation position

To determine the correct position of the AirFlow P, proceed as follows:

- The sensor can be used in round or angular pipes. In the case of horizontal or sloping pipelines, the installation should be carried out from above.
- Depending on the geometry and size of the line to be monitored, several sensors are used:
 - From a line size of 1500 mm 2 sensors are used.
 - From a line size of 3000 mm 3 sensors are used.
- If several sensors are required for one measuring point, all sensors are distributed evenly on the line at one installation height.

Optimally, the duct or pipeline continues horizontally or vertically upstream and downstream of the installation point, and fixtures such as bends, flaps or gate valves have a minimum distance to the sensor in both directions. (See Fig. 6)





Fig. 6: Recommended distances to valves, etc. (DN = nominal diameter)



In applications where the mounting location requirements cannot be fully met, the best possible mounting position should be selected.

1. The AirFlow P should be installed so that the two antennas of the sensor are aligned with the material flow.
2. In horizontal pipes with a round cross-section, the AirFlow P can be installed in any position above the horizontal axis (between 9 and 3 o'clock).
3. In horizontally running lines with a square cross-section, the installation can take place centrally at the top or at the side.
4. Even if the sensor is not impaired in its function by vibration, strong vibrations should be avoided as they can lead to the destruction of the electronics.
5. The sensor should not be exposed to direct sunlight, nor should it be used in areas with an ambient temperature of more than 60 °C.
6. The sensor rods must not have any contact with the opposite line wall or any other device! This would short-circuit the electrodynamic signal. To prevent this condition, the length of the antennas can be shortened to a minimum length of 120 mm. The length of the antennas is measured from the end of the screw-in thread.
The ceramic sleeve must not be damaged in any way.
7. The length of the sensor rods should be at least $\frac{1}{3}$ and at most $\frac{2}{3}$ of the duct diameter. In any case, it must be ensured that no contact occurs due to bridging in the event of coating formation on the inner wall of the pipe.

4.4 Installation in non-metallic lines

The sensor must be installed in a metallic duct to achieve sufficient shielding against electrical influences. In the case of non-metallic ducts, a sheathing of metal, a metal foil or a fine-meshed metal mesh with a length of approx. 5 times the pipe diameter must be made upstream and downstream of the measuring point. Furthermore, make sure that the duct and the sensor are well grounded.

4.5 Installation of the sensor

At the selected installation position, the double weld-on sleeve must be installed on the line wall and drilled out completely to the inner diameter of the sleeve. The sleeve must be installed with the material flow direction.



Attention!

- After drilling, it is essential to check whether any burr has formed on the drill edges as a result of drilling. Any burr that may have arisen in the pipe must be removed with an appropriate tool. If the burr is not removed, this can have an influence on the calibration of the sensor!
- The two antennas are then screwed in tightly. The connections are to be checked for tightness, appropriate sealing tape is to be used.
- Once both antennas are installed, the electronics box is pushed onto the antennas and secured using the TriClamp connection. If the installation is correct, it should be possible to insert the connectors of the electronics box into the antennas with a perfect fit.
- If the sensor is not installed immediately, the sealing caps must be screwed in until the time of installation.



Attention!

- Use the correct tool (spanner size = S36) and apply it to the G 1" screw connection.
- Use sealing tape
- Improper installation will void the warranty!
- Observe the seal on the TriClamp connections!

4.6 Dimensions




Fig. 7: Dimensions of the MSE 300-DR




Fig. 8: Dimensions of the MSE 300-FH (front view)





Fig. 9: Dimensions of the MSE 300-FH (side view)




Fig. 10: Dimensions C1 box




Fig. 11: Dimensions G 1" double socket






Fig. 12: Dimensions AirFlow P sensor



5. Electrical connection

The evaluation unit can be installed at a maximum distance of 300 m from the sensor.

A cable of the type „Ölflex Classic 110 CY“ is recommended. The cable should be four-core, twisted in pairs and shielded. A minimum cross-section of 0.75 mm² should be observed. For distances of 150 m and more, the cross-section should be adjusted.

5.1 Terminal assignment MSE 300-DR

1 Current output - 4 ... 20 mA	2 Current output + 4 ... 20 mA	3 Input Power supply 0 V DC	4 Input Power supply + 24 V DC
5 Not used	6 Alarm relay NC (break contact)	7 Alarm relay C	8 Alarm relay NO (make contact)





Fig. 13: Electrical connection of the MSE 300-DR

9 Digital pulse output (-)	10 Digital pulse output (+)	11 RS 485 Interface Data B	12 RS 485 Interface Data A
13 Sensor connection Cable 4 RS 485 Data B	14 Sensor connection Cable 3 RS 485 Data A	15 Sensor connection Cable 2 Power supply 0 V	16 Sensor connection Cable 1 Power supply + 24 V



5.2 Terminal assignment MSE 300-FH




Fig. 14: Electrical connection of the MSE 300-FH

Evaluation unit			
Terminal No.	Connection		
Power supply connection			
L / +24 V	Input power supply 230 V / 50 Hz, 110 V / 60 Hz (optional 24 V DC)		
N / 0 V	Input power supply 230 V / 50 Hz, 110 V / 60 Hz (optional 24 V DC)		
PE	Earth		
Connections			
I-in1	+	Current input +	
	-	Current input -	
I-out1	+	Current output +	
	-	Current output -	
	Na	Not used	
	Na	Not used	
	Na	Not used	
	Na	Not used	
Min. / Max.-Relay	NO	Floating change-over contact NO (make contact)	
	C	Floating change-over contact C (common conductor)	
	NC	Floating change-over contact NC (break contact)	
D-out	+	Digital pulse output +	
	-	Digital pulse output -	
RS 485	A	RS 485 interface data A	
	B	RS 485 interface data B	
	GND	RS 485 interface ground	
D-in1	+	Digital interface 1 (+)	
	-	Digital interface 1 (-)	
D-in2	+	Digital interface 2 (+)	
	-	Digital interface 2 (-)	
Sensor	+	Power supply + 24 V	Cable no. 1
	GND	Power supply 0 V	Cable no. 2
	A	RS 485 data A	Cable no. 3
	B	RS 485 data B	Cable no. 4
	Shield	Shield	

5.3 Terminal assignments C-Boxes





Fig. 15: Electrical connection C3-Box



Sensor 1 / 2 / 3


- 1 Power supply + 24 V
- 2 Power supply 0 V
- 3 RS 485, data A
- 4 RS 485, data B
- S Shield

Evaluation unit

- 1 Power supply + 24 V
- 2 Power supply 0 V
- 3 RS 485, data A
- 4 RS 485, data B
- S Shield

Cable gland
M 20 x 1.5

Fig. 16: Electrical connection C1-Box



5.4 Terminal assignment sensor

PIN 1: +24 V DC

PIN 2: GND

PIN 3: ModBus A

PIN 4: ModBus B





Fig. 17: Electrical connection of the plug connector



6. Operator interface

The Evaluation unit is a multi-sensor Evaluation unit. It is therefore strongly recommended that you check whether the correct sensor has been selected under the **System** menu item before commissioning.

The user interface appears differently depending on the system configuration:

- Top-hat rail housing without display, operation via PC software
- Field housing with touch-sensitive display, alternative operation via PC software

The following illustrations first highlight the variants of the system. In the further course, the basic operation of the AirFlow P system is then described without going into the differences between the various variants again.

6.1 Differences between the Evaluation units DIN rail or field housing


The Evaluation unit in the top-hat rail housing represents only a part of the functions that are available in the field housing. The following overview describes the differences between the two variants.

Function	Field housing	DIN Rail
Menu system		
• via PC software	yes	yes
• via display	yes	no
Measurement value display current output	yes	yes
Pulse output for the control of solenoid valves or for totaliser output	yes	yes
Alarm system relay output	yes	yes
Autocorrect analogue input	yes	no
Error output		
• on current output	yes	yes
• at relay	yes	yes
• via PC software	yes	yes
• via display	yes	no
• on status LED	no	yes

The Evaluation unit in the top-hat rail is configured exclusively via a USB connection and a PC program. With the Evaluation unit in the field housing, all functions can be configured menu-driven via the touch-sensitive display.


PC configuration is also possible with the Evaluation unit in the field housing.

The menu items in the display and in the PC software are numbered uniformly, so that reference is made to this numbering in the following.




6.2 Display

The display is touch-sensitive. Available keys are displayed directly in context. When the measuring system is started for the first time, a query is initiated to select the language and the sensor. If no selection is made, the initialization disappears and the German language with an AirFlow P sensor is selected.



Initialization screen when the Evaluation unit in the field housing started first time.


Selection of the menu language:
Deutsch, English, Français



If a language has been selected, the sensor to be used must be selected.


To be available:
SolidFlow 2.0, Paddy, PicoFlow, MaxxFlow HTC, DensFlow, AirFlow P, SpeedFlow 2.0, SlideControl 2.0, ProSens, M-Sens 2, M-Sens 3, M-Sens WR, M-Sens WR2.

Afterwards the start page appears.



The start page in the display shows the following values:


- Name „AirFlow P“, a freely selectable text describing material or measuring point
- Measured value, here in [m/s]
- The [I] key for Info



To enter the main menu, the display must be switched to button at any point for several seconds. The selection of submenus appears.

In the menus and input fields, the displayed keys can be used to browse, select, edit or reject:

- [Arrow]: Scroll down the page, Select an option, Select a position in the input text
- [E] for ESC: Interrupt the function without making any changes
- [←]: Select the function or confirm the input
- [C] for Clear: Delete a symbol or number.



Sensor status			
	Temp	raw value	Stat
S1	63.0	0.000123	OK

The [I] key can be used to call up an information window.
The first window displays the raw values, temperature and the status of the sensor.
The error memory is displayed in the second window. The most recent error codes are always listed first. If an error code repeats itself, it will appear first, but will not be listed more than once.

Save changes?	
<input type="checkbox"/> Y	<input type="checkbox"/> N


If any data has been changed, the change will only be taken into account when you exit the complete menu structure and answer [Yes] when asked if you wish to save the changes.

For reasons of clarity, no further presentation of the display menus is provided. The display representations are derived directly from the menu structure in section 6.4.

Protection against unauthorized use:

If a password has been entered in menu **7. System** in **7.6 Password**, which is different to the "0000" default setting, you will be asked to enter a password when attempting to access the menus.

After the password has been successfully entered, the menus will be unlocked for approx. 5 minutes (from the last menu entry).



6.3 PC interface

With both the DIN Rail and field housing version, communication with a laptop or PC is optionally performed either at the terminals via an RS 485 or at the front via a USB interface.

- ✓ The **RS 485 connection** is attached to the MSE 300 in the field housing at the ModBus A (+) and ModBus B (-) terminals. On the DIN Rail version, these connections are no. 12 and 11, accordingly. RS 485 is a bus connection; the ModBus address and the baud rate can be set on the device.

Upon delivery, the communication parameters are set to:

- ModBus address 1
- Baud rate 9600, 8, E,1
- Parity: even


An RS 485 to USB adapter can be purchased from ENVEA Process.


- ✓ A standard USB-A-B cable is supplied for the USB connection to the DIN Rail version. The USB connection is a point-to-point connection that is BUS-enabled. The ModBus address and baud rate for the front connections cannot be changed and are always:

- ModBus address 1 (or the device answers to all addresses)
- Baud rate 9600, 8, E,1
- Parity: even (parity can not be changed on the USB connection)

When connected to the PC for the first time, any interface drivers enclosed with the Evaluation unit must be installed.

After starting the software, the communication parameters must first be entered accordingly. These can be found in the top left of the program window. The COM port to be configured is displayed in the device manager.





Communication is established by clicking on “Read device”. The acknowledgement message “Parameter read in” is displayed. If an error message is displayed instead, check the communication parameters and cable connections between the PC and the Evaluation unit.

The edited data is transmitted to the Evaluation unit via “Program device”. Critical data concerning the ModBus communication and the calibration must be confirmed before the parameters are transmitted to the Evaluation unit:

- ✓ If, when saving the parameters in the Evaluation unit, the system calibration data is changed, this action must be confirmed by checking “Overwrite calibration”.
- ✓ If, when saving the parameters in the Evaluation unit, the system interface parameters are changed, this must be confirmed by checking the selection “Overwrite baud r./address”.


In addition, with the PC software,

- the parameters of the Evaluation unit can be saved in a file (Save configuration)
- the parameters of the Evaluation unit can be loaded from a file (Load configuration)
- the parameters of the Evaluation unit can be printed via the set Windows standard printer (Print configuration)
- the measured values can be logged in a data logger file (enter the file name and storage rate, and activate the data logger on the online display)

The software language can be set by right-clicking the “Sprache/Language/Langue” field in the bottom program line on “Deutsch/English/Français”.

Protection against unauthorised use:

The PC interface does not have a password prompt as it is assumed that only authorised personnel will have access to the PC and the software. However, the password to operate the display can be read and changed in menu **7. System** under **7.6 Password**.




6.4 Menu structure


The menu structure supports the user when adjusting the measuring range, the calibration, the measurement values and the choice of additional functions. In this connection, the numbering both on the display and in the PC interface is identical:

1. Measurement range

Setting all relevant measuring range settings




1.1 Tag No.	Input: Free text (10 characters)	Name of the measurement point or product.
1.2 Unit	Selection: m/s, mm/s, ft/s	Desired unit of speed.
1.3 Decimal point	Selection: 0000, 0.000, 00.00, 000.0	Number representation and decimal point-accuracy in the measurement menu.
1.4 Set point low	Input: 0 ... 9999	Speeds under this value will not be displayed at the current output. The display is not affected by this.
1.5 Set point high	Input: 0 ... 9999	Speeds under this value will not be displayed at the current output. The display is not affected by this.
1.6 Filter	Input: 0.0 s ... 999.9 s	Filtering of measurement for the indicator and the output values.




2. Calibration

Storing a correction factor




2.1 Calibration factor **Input:** 0.01 ... 9.99 Value for adjusting the measured speed.




3. Alarm

Settings for the alarm via the relay contacts




3.1	Alarm type	Selection: Min / Max / None	The relay is activated when the measured value exceeds the Max. limit or undershoots the Min. limit.
3.2	Alarm value	Input: 0 ... 999.9	Limit value for monitoring Min. or Max.
3.3	Delay	Input: 0.1 ... 99.9 s	The value must permanently exceed or fall below the set limit during this time.
3.4	Hysteresis	Input: 0.1 ... 99.9 %	The alarm continues for as long as the measurement is not smaller or larger than the limit value plus or minus hysteresis.
3.5	Operation mode	Selection: Working / closed current principle	NC: the relay is closed, as long as no alarm is active. NO: the relay is closed, if there is an alarm.
3.6	Sensor alarm	Selection: OFF /ERR / PROC	Off: Sensor or process indicators are not displayed at the relay. ERR: Serious internal sensor errors trigger an alarm at the relay. PROC: Serious internal sensor errors and process indicators trigger an alarm at the relay. Further information on the signalling levels ERR or PROC can in chapter Fault clearance.



4. Analogue output

Setting and calibrating the analogue output




4.1	Lower limit	Input: 0 ... 22 mA	Standard setting: 4 mA
4.2	Upper limit	Input: 0 ... 22 mA	Standard setting: 20 mA
4.3	Alarm value	Input: 0 ... 22 mA	Value to be output at pending alarm (Standard setting 2 mA)
4.4	Alarm mode	Selection: Hold alarm / output	Alarm: Alarm is output Measurement value drops to 0, or current measurement value. Hold output: Last measurement value remains pending until fault rectification at the output signal.
4.5	Analogue output 1	Submenu	
4.5.1	Calibration 4 mA	Selection: Setting the output current	Key functions can be used to set the current and equalise it to the receiver side.
4.5.2	Calibration 20 mA	Selection: Setting the output current	Key functions can be used to set the current and equalise it to the receiver side.
4.6	Analogue output 2	Submenu	
4.6.1	Calibration 4 mA	Selection: Setting the output current	Key functions can be used to set the current and equalise it to the receiver side.
4.6.2	Calibration 20 mA	Selection: Setting the output current	Key functions can be used to set the current and equalise it to the receiver side.

- | | | | |
|-------|-------------------|---|--|
| 4.7 | Analog output 3 | Submenu | |
| 4.7.1 | Calibration 4 mA | Selection:
Setting the output current | Key functions can be used to set the current and equalise it to the receiver side. |
| 4.7.2 | Calibration 20 mA | Selection:
Setting the output current | Key functions can be used to set the current and equalise it to the receiver side. |


The current output can be calibrated so that the zero point (output of 4 mA) is set to the background noise of the measuring point. If the background noise decreases due to process changes, sensor wear or other ageing effects, a signal of less than 4 mA can be output at the analogue output. In this way, a zero offset can be detected (zero point drift). If this function is not desired for process engineering reasons, the zero point must be specified for the calibration to a raw value of zero and/or the **4.1 MIN limit** set to 4 mA.

If the settings of the 4 mA or 20 mA signal are changed, a check mark must be placed by **Overwrite I/O calibration**.




5. Pulse output

Passive signal for pulse cleaning.




- | | | | |
|-----|--------------|----------------------------------|--|
| 5.1 | Function | Selection: OFF / Cleaning | OFF: No pulse output
Cleaning: Option for actuation of a solenoid valve for pneumatic air flushing. |
| 5.2 | Pulse period | Input: 1 s ... 600 s | Duration between two pulses |
| 5.3 | Pulse length | Input: 1 s ... 60 s | Length of the pulse |



6. Current input

Option for auto-correction by external current signal.




The signal is not electrically isolated.

If the connection is incorrect, the CPU of the Evaluation unit may be destroyed.


An external, galvanic isolation by means of a current disconnecter or similar must be provided.

6.1	Input calib. 4 mA	Selection: Set input current	The 4 mA signal must be read in via key functions.
6.2	Input calib. 20 mA	Selection: Set input current	The 20 mA signal must be read in via key functions.
6.3	Correction	Selection: ON / OFF	ON: Activation of the correction. OFF: Deactivation of the correction.
6.4	P1 input	Input: 4 mA ... 20 mA	Entry of the current that is to be used for the correction.
6.5	P1 factor	Input: 0.01 ... 10	Factor for subsequent adjustment of the actual measurement value.
6.n	Pn input	Input: 4 m A ... 20 mA	Option for further entry of current value and correction factors.
6.n	Pn factor	Input: 0.01 ... 10	




7. System


Basic settings of the system and the Evaluation unit



- | | | | |
|-------|---------------------|--|--|
| 7.1 | Language-controller | Selection: D / E / F | Selection of the language on the display of the Evaluation unit |
| 7.2 | Sensors | Submenu | |
| 7.2.1 | Sensor 1 | Selection: ON | Sensor 1 is always active and cannot be switched off. |
| 7.2.2 | Sensor | Selection:
SolidFlow 2.0 / Paddy /
PicoFlow / MaxxFlow HTC /
DensFlow / SpeedFlow 2.0 /
SlideControl 2.0 / ProSens /
M-Sens 2 / M-Sens 3 /
M-Sens WR2 | The Evaluation unit checks whether the sensor connected to the matches with the sensor set for based on the set sensor the measured values are calculated and possible errors are displayed. Incorrect sensor selection leads to communication denial. |
| 7.3 | Display | Submenu | |
| 7.3.1 | Sensor info | Selection: ON /OFF | ON: The key for querying sensor information is shown on the display.
OFF: The key for querying sensor information is hidden on the display. |




7.3.2	Process indicator	Selection: ON /OFF	ON: Process indicators are shown on the display and indicated on the DIN Rail by flashing twice. OFF: Process indicators are not output.
7.3.3	Backlight	Input: 0 min ... 99 min	Display lighting in minutes 0 = Permanent lighting 99 = Time selection for lighting
7.3.4	Contrast	Input: 0 ... 100 %	In the event of an inadequate display, the contrast can be changed via the PC software, if necessary.
7.4	Address	Input: 1 ... 255	ModBus address of Evaluation unit, if this is operated on a PLC or PC as a ModBus slave (RS485 connection).
7.5	Baud rate	Selection:	Communication speed of the Evaluation unit if 4800 / 9600 / 19200 / 38400 operated on a PLC or PC as a ModBus slave.
7.6	Parity	Selection: Even/Odd/None	The parity is set to even by default. The parity is important for further communication. A change of the parity is only valid after a restart of the power supply.
7.7	Password	Input: 0 ... 9999	0 = No password protection XXXX = Four digit password that is queried when calling up the menu on the display Automatic locking for five minutes after the last display input.
7.8	Init Screen	Selection:	If Init Screen is selected, the Evaluation unit is reset to factory settings after the next voltage reset.



8. Service

Display of the sensor status




In menu **8. Service** the status of each connected sensor is displayed. FW type, FW version, temperature, serial number and possible hardware errors are automatically read in and displayed.

In the case of a change of display, the PC software can be used to adjust the contrast, if necessary.

Only by instruction of trained personnel from ENVEA Process:

If a detailed error analysis is necessary, you can use the PC software by clicking on **Sensor Dump** to save a copy of all ModBus registers as a text file in the installation folder of the software. This is possible only with the PC software. In addition, a service program with deeper access to the sensors can be launched via the PC software.

Only the information on the status of the individual sensors is output on the field housing display.



7. Start-up procedure

7.1 Basic start-up procedure

The sensor is an absolute measuring device and must be parametrised during the commissioning procedure.

The following points must be checked before parametrisation:

- The correct installation of the sensor in the conveyor line.
- The correct connection between the sensor and the Evaluation unit.
- A warm-up time of approx. 5 minutes before starting parametrisation and after switching on the sensor's power supply.

At the beginning of the calibration, it must be checked whether the correct sensor is selected under the menu item **7. System**. If the correct sensor has been selected, the desired measuring range and the physical unit are entered in **1. Measuring range**.

Once all parameters are correctly stored, the sensor transmits a measured value. No extensive calibration is required beyond the defined distance of both measurement antennas and the internal correlation of the measured values. Should the measured speed nevertheless deviate from a reference speed, the value can be adjusted via **2.1 Calibration factor**.


7.2 Datalogger function in the software

To determine the raw values via the Datalogger function of the PC software, a file path first must be stored. The file path and file name can be selected by clicking on the folder icon next to File name. If the file path is stored, the sample rate could still be changed, this is recommended for long recordings. For determining the raw values for a calibration point, the default setting of 1 (raw value) / second is recommended.

To start the datalogger, the **On-line representation** must be started. As soon as the checkbox on **Datalogger activated** is set in the on-line display, the recording starts and the log file is created in the background.

The data logger is only activated as long as the on-line representation is open. If the window of the on-line display or the entire software is closed, the data recording is aborted. If the data logger is activated, a message window also appears before the on-line representation is closed.


For an evaluation of the recorded log file, it must be opened with Excel or a similar program.



7.3 Adjusting the measurement values

The system's additional functions can be set in the following menus:

Alarms	Throughput upper/lower limit values can be set in 3. Alarm . A sensor monitoring alarm can also be activated here.
Analogue output	The analogue output values are assigned in 4. Analogue output . Upper and lower limits of the permitted power and fault current are set here. The analogue output is an active signal. In the field housing design, analogue output 2 + 3 are provided for the MaxxFlow HTC. All other sensors output their 4 ... 20 mA signal to analogue output 1.
Pulse output	In 5. Pulse output there is an option to use different pulses. A cleaning pulse can be used for a possible pneumatic cleaning on the sensor.
Current input	In 6. Current input different input currents can be stored. When the current is applied, the corresponding correction factor is applied to the measured value. The input current can also be equalised here.
System	In 7. System functions such as selection of the menu language, the number of connected sensors and their average, the display screen or ModBus addressing and speed are summarised.



8. Error signalling

To monitor availability, comprehensive system diagnostic functions have been integrated to signal various errors:

1. Serious errors (ERR):

Serious errors (ERR) always set the current output to the configured alarm value. Technical problems affecting the sensor or the entire system that require replacement or repair of a component are displayed:

- Failure of the communication to a sensor (sensor failure)
- Failure of a subcomponent of a sensor (temperature monitoring, heater control, memory, data consistency, etc. on the sensor)
- Inconsistent signal paths in the sensor (amplifier stages, DC offsets)

2. Process indicators (PROC):

Process indicators (PROC) merely report a violation of set parameters and should be viewed as information to improve the measurement process.

Process indicators are not output at the current output, however they can be shown on the display (field housing) or the RUN LED (DIN Rail) and optionally on the relay:

- Temperature instability in the sensor due to external thermal stress (overtemperature, low temperature)
- Overload of the sensor due to material flow (too much, too little)

Process indicators may also only show temporary abnormalities in the process, which can be prevented by optimising the sensor or delivery parameters.

Process indicators are not sensor errors, but rather provide information about optimisation potential at the measuring point.

Display	Display (field housing)	Run LED (DIN Rail)	Relay (optional)	Current output
No error	Sensor status OK in the information display ([I] key)	Single flashing every second	Normal status	4 ... 20 mA
PROC (Process indicators)	Display with indicator code in the bottom display line, extended information via [I] key	Double flashing every second	Enabled if relay alarm option PROC is selected	4 ... 20 mA
ERR (Hardware error)	Display with error code in the bottom display line, extended information via [I] key	Triple flashing every second	Enabled if relay alarm option PROC <u>or</u> ERR is selected	2 mA (or alarm value set for the current output)

Error codes: Error and indicator codes are composed of the letter E (ERR = error) or P (PROC = process indicator) and a three-digit hexadecimal value from "000" to "FFF". The cause can be determined via the displayed code.

Error timeout: In order not to complicate the start-up of a processing plant due to process and heating status errors, non-serious errors are only signalled at the outputs after approx. 5 minutes have elapsed following a reset of the measuring system. The timeout delay is indicated by a small "t" in the upper-left corner of the display (field housing only).

9. Maintenance



Warning!

- Switch the power supply off before performing any maintenance or repair work on the measuring system. The transport pipe must not be operational when replacing the sensor.
- Repair and maintenance work may only be carried out by electricians.
- The system requires no maintenance.

10. Warranty

On condition that the operating conditions are maintained and no intervention has been made on the device and the components of the system are not damaged or worn, the manufacturer provides a warranty of 1 year from the date of delivery.

In the event of a defect during the warranty period, defective components will be replaced or repaired at ENVEA Process plant free of charge at the discretion of ENVEA Process. Replaced parts will become the property of ENVEA Process. If the customer requests that parts be repaired or replaced at its plant, the customer must pay the travel expenses for ENVEA Process service personnel.

ENVEA Process cannot accept any liability for damage not suffered by the goods themselves and in particular ENVEA Process cannot accept liability for loss of profit or other financial damages suffered by the customer.


11. Fault clearance



Warning!

- The electrical installation may only be inspected by trained personnel.


Error	Cause	Action
Measuring system does not work. POW LED does not light up. RUN LED does not light up.	Power supply interrupted.	Check the power supply.
	Cable break.	Check the connection cables for a possible cable break.
	Defective fuse.	Replace fuse.
	Defective device.	Notify ENVEA Process and rectify the error as instructed on the telephone.
Measuring system does not work. POW LED does not light up. RUN LED does not light up.	Microprocessor does not start.	Switch the power supply off and on again. Remove programming cable.
Measuring system works. POW LED does not light up. RUN LED flashes twice or three times per cycle.	No sensor communication.	Sensor defective. Cable break between sensor and measuring system.
	Sensor connected incorrectly.	Check connection cable.
	Sensor defective.	Replace sensor.
	Sensor not receiving 24 V supply.	Make sure the power supply is connected.
	Excessive voltage drop in the supply cable to the sensor.	Check cable lengths.
	Error code available on the display.	Additional error diagnosis by error code.
Measuring system outputs incorrect values.	Calibration incorrect.	Perform a recalibration.
	Calibration shifted by abrasion on the sensor head.	Perform a recalibration.
Switch output relay chatters.	Hysteresis too low.	Increase hysteresis. Check for fault caused by external consumer.
Do not open sensor electronics. To do so will make the warranty void!		



11.1 Error codes

Type	Error code	DR flashing	Current	Description	Remedy
ERR	E0001	3	2 mA	Internal amplifier defective (DC offset)	Switch off power supply for at least 10 s, if not helpful: replace, check parameters
PROC	P0002	2	4...20 mA	Signal too small	Process stopped? Check parameters
ERR	E0004	3	2 mA	Defective speed electrode	Check parameters, set fixed speed or replace sensor
ERR	E0008	3	2 mA	Defective speed electrode	Check parameters, set fixed speed or replace sensor
ERR	E0010	3	2 mA	Asymmetrical speed signal	Check parameters, set fixed speed or replace sensor
PROC	P0020	2	4...20 mA	Inverted input signal on a channel	Check parameters, set fixed speed, replace sensor
PROC	P0040	2	4...20 mA	Measurement range exceeded	Set parameters, check process
PROC	P0080	2	4...20 mA	Measurement range exceeded	Set parameters, check process
PROC	P0100	2	4...20 mA	Poor result of individual measurement	Set parameters, set fixed speed, check process
PROC	P0200	2	4...20 mA	Periodic speed signal	Set parameters, set fixed speed, check process
PROC	P0400	2	4...20 mA	Speed too high, signal cannot be measured	Set parameters, set fixed speed, check process
PROC	P1000	2	4...20 mA	Negative speed measurement	Set parameters, configuration flags, set fixed speed, check process
PROC	P2000	2	4...20 mA	Empty calculation buffer	Wait, reset if necessary if not gone after some time

A detailed error description and subsequent troubleshooting can be carried out by trained ENVEA Process GmbH personnel.



12. Technical data

Sensor	
Power supply	24 V DC, fed by Evaluation unit
Measuring range	from 1 mg/m ²
Speed range	1 m/s ... 100 m/s
Process temperature	-20 ... +250 °C
Ambient temperature	-20 ... +60 °C
Housing material	Aluminium
Sensor rod material	Stainless steel
Protection type	IP65
Dimensions	220 x 840 x 120 mm (W x H x D)
Weight	5.5 kg
Evaluation unit MSE 300-FH	
Power supply	110/230 V, 50 Hz (optional 24 V DC)
Power consumption	20 W / 24 VA
Protection category	IP65 to EN 60 529/10.91
Ambient operating temperature	-10 ... + 45°C
Dimensions	258 x 237 x 174 (W x H x D)
Weight	Approx. 2.5 kg
Interface	RS 485 (ModBus RTU) / USB
Cable screw connectors	3 x M20 (4.5 - 13 mm Ø)
Connection terminals cable cross-section	0.2 - 2.5 mm ² [AWG 24-14]
Current output	3 x 4 ... 20 mA (0 ... 20 mA) load < 500 Ω (Active)
Relay contact	Max. rated load: 250 V AC Max. peak current: 6 A Max. rated load 230 V AC: 250 VA Max. breaking capacity DC1: 3/110/220 V: 3/0.35/0.2 A Min. switching load: 500 mW (10 V/5 mA)
Data backup	Flash memory
Pulse output	Open collector - max. 30 V, 20 mA
Evaluation unit MSE 300-DR	
Power supply	24 V DC 3 10 %
Power consumption	20 W / 24 VA
Protection category	IP40 to EN 60 529
Ambient operating temperature	-10 ... +45 °C
Dimensions	23 x 110 x 121 (W x H x D)
Weight	Approx. 190 g
Interface	ModBus RTU (RS 485) / USB
DIN Rail fastening	DIN 60715 TH35
Connection terminals cable cross-section	0.2 - 2.5 mm ² [AWG 24-14]
Current output	2 x 4 ... 20 mA (0 ... 20 mA) load < 500 Ω (Active)
Relay contact	Max. rated load: 250 V AC Max. peak current: 6 A Max. rated load 230 V AC: 250 VA Max. breaking capacity DC1: 3/110/220 V: 3/0.35/0.2 A Min. switching load: 500 mW (10 V/5 mA)
Data backup	Flash memory
Pulse output	Open Collector - Max. 30 V, 20 mA



ENVEA Process GmbH
 Gutedelstraße 31 · 79418 Schliengen (Germany)
 Fon +49 7635 827248-0 · Fax +49 7635 827248-48 · www.envea.global
PART OF THE ENVEA GROUP

